
Contents

1	Introduction	1
2	Safety Information	2
2.1	Warnings, Cautions and Notes	2
3	Data	3
3.1	Environmental	3
3.2	Electromagnetic Compatibility	3
3.3	Electrical ratings	3
4	Installation	5
4.1	Environment	5
4.2	Mounting instructions	6
4.3	Recommended wiring practices	8
4.4	Ground connections	9
4.5	Power connections	9
4.6	Control signal connections	10
4.7	User signal connections	13
4.8	Using Braking Units with parallel Drives	14
4.9	Control during loss of AC supply	14
4.10	Power-limit protection system	15

